



NOTES:

1. FOR STAINLESS STEEL FITTINGS INTO STAINLESS STEEL THREAD, USE PIPE DOPE OR TEFLON TAPE, NOT BOTH.
2. FOR PLASTIC FITTINGS INTO STAINLESS STEEL THREAD, USE BOTH PIPE DOPE AND 2 LAYERS OF TEFLON TAPE.

TO ORDER LATERAL ASSEMBLY CONTACT:

CORRECT EQUIPMENT, INC.
 300 S REDWOOD ST
 CANBY, OR 97013



ROGUE VALLEY SEWER SERVICES

138 WEST VILAS ROAD, CENTRAL POINT, OREGON 97502
 (541) 779-4144, Fax (541) 664-7171

E-ONE GRINDER PUMP LATERAL ASSEMBLY
 (INTEGRATED STAINLESS STEEL BALL VALVE
 & CHECK VALVE)

Rev. 2/8/2022 (NRB)
 Rev. -

STANDARD
 DRAWING
 NO. 10-4
 DATE: 2/22