



NOTE: INSTALL TRACER WIRE FULL LENGTH OF PIPE (18 GAUGE INSULATED COPPER WIRE FROM THE MAIN TO THE PROPERTY LINE OR 14 GAUGE FROM THE PROPERTY LINE TO THE HOUSE). LEAVE ONE END CLEARLY MARKED ABOVE FINISHED GRADE. WHEN CONNECTING TO EXISTING TRACER WIRE, USE A WATER TIGHT WIRE CONNECTOR OR INSTALL C.O WITH BOTH ENDS OF TRACER WIRE CLEARLY EXPOSED ABOVE FINISHED GRADE.

STANDARD SERVICE CONNECTION
DETAIL FOR DEEP TRENCHES AT
DISCRETION OF DISTRICT ENGINEER



**ROGUE VALLEY
SEWER SERVICES**

138 WEST VILAS ROAD

CENTRAL POINT, OR.

**SERVICE LATERAL CONNECTION
DETAILS**

Rev.12/98
Rev.9/07

STANDARD
DRAWING
NO.
5-1
DATE: 9/07